





# PRODUCT INFORMATION SHEET

## CONTROL PANEL - ROTISSERIE

INFINITY MODEL

The information contained in this technical data sheet is based on the best data available at the time of publication and shall not hold the manufacturer liable in the event of non-compliant use.



**SHEET NO. 40017**

THE LINE® Technology

Number	Function / Usage
A	Touch switch: Lowers rotisserie power
B	Touch switch: Increases rotisserie speed
C	Removable handle

Rotisserie LED Colors A & B
Off > White
1–2 rpm > Green
3–4 rpm > Blue
5–6 rpm > Purple
7–8 rpm > Red



Copyright THE LINE® GRILL  
Paulus Industries - 2025